

CONTENTS - National Semiconductor Audio/Radio Handbook - code 6001

title
1.0 Introduction
1.1 Scope of Handbook
1.2 1C Parameters Applied to Audio
2.0 Preamplifiers
2.1 Feedback - To Invert or Non-Invert
2.2 Design Tips on Layout, Ground Loops and Supply Bypassing
2.3 Noise
2.4 Audio Rectification - or, "How Come My Phono Detects AM"
2.5 Dual Preamplifier Selection
2.6 LM381
2.7 LM381A
2.8 LM387orLM387A
2.9 LM382
2.10 LM1303
2.11 Phono Preamps and RIAA Equalization
2.12 Tape Preamps and NAB Equalization
2.13 Mic Preamps
2.14 Tone Controls - Passive and Active
2.15 Scratch, Rumble and Speech Filters
2.16 Bandpass Active Filters
2.17 Octave Equalizers
2.18 Mixers
2.19 Driving Low Impedance Lines
2.20 Noiseless Audio Switching
3.0 AM, FM and FM Stereo
3.1 AM Radio
3.2 LM3820
3.3 PM-IP Amplifiers/Detectors
3.4 LM3089 - Today's Most Popular FM-IF System
3.5 LM3189
3.6 FM Stereo Multiplex - LM1310/1800
3.7 Stereo Blend - LM4500A/LM1870
4.0 Power Amplifiers
4.1 Inside Power Integrated Circuits
4.2 Design Tips on Layout, Ground Loops and Supply Bypassing
4.3 Power Amplifier Selection
4.4 LM1877/378/379/1896/2887/2896
4.5 LM380
4.6 LM384
4.7 LM386
4.8 LM389
4.9 LM388
4.10 LM390
4.11 LM383
4.12 Power Dissipation