

Elma 2 pole 6 way selector switch



front view with knob fitted



To change to a 2 pole/2 way/3 way/4 way/5 way, screw the locator screw into the correct numbered hole on the front of the selector switch